

PP005946.TIF DF8ALK11(P1) K11 2011 / * CATALOG PREFACE *

PREFACE

When it becomes necessary to replace parts on SUZUKI OUTBOARD MOTORS, always use SUZUKI GENUINE PARTS which have passed a strict inspection which guarantees quality and performance.

This parts catalogue covers the list of all service parts for SUZUKI DF8A (R), DF9.9A (R) '10 MODEL and later.

INSTRUCTIONS FOR QUOTING THE CATALOGUE

1. **DIMENSIONS**
Dimensions of the parts in this catalogue are indicated in unit millimeters.
2. **ABBREVIATIONS**
Abbreviations used in this catalogue are as follows:

AR	: As required	NT	: Number of teeth
ASSY	: Assembly	OPT	: Optional
E. NO.	: Engine number	OS	: Over size
F. NO.	: Frame number	STD	: Standard
D	: Diameter of material	T	: Thickness
ID	: Inside diameter	US	: Under size
OD	: Outside diameter	W	: Width
L	: Length	W/	: with
LH(PORT)	: Left hand side	S, L	: Transom type
RH(STBD)	: Right hand side	SUS	: Stainless steel
~123456	: Up to E. NO. 00994F-123456		
123456~	: From E. NO. 00994F-123456		

12 x 34 x 5.6..... Figures in the description column
 | | | show the dimensions of parts.
 ID OD T (or W, L)

→12345-56781 (Parts No.) : indicates that the parts number was changed to 12345-56781 and the new parts are interchangeable with the former ones but the former ones are not interchangeable with new ones.

←12345-56781 (Parts No.) : indicates that the former and new parts are interchangeable with each other and both are usable.

3. **INNER PARTS OF ASSEMBLY**
Part name with a dot (.) in front as shown in the description column indicates the component of the assembly also available individually.
4. **MODIFICATION NOTICE**
A parts bulletin will be sent to you on all occasions when changes in parts

DF8A/9.9A P1

- 1 -

PP005932.TIF DF8ALK11(P1) K11 2011 / * CATALOG PREFACE *

No Image
Available

PP005937.TIF DF8ALK11(P1) K11 2011 / * CATALOG PREFACE *

5. NOTE

5-1. There are some different parts from those of production models among spare parts for the administrative reasons and common use of them with other models.

5-2. In respect of rubber hoses and vinyl tubes, please be sure to use them by cutting off according to the length mentioned on parts catalogue or what is actually required on the vehicle.

5-3. Note that the drawings on the illustration page are for ready reference of spare parts number, not to be used as an assembly manual. When assembling, use "SUZUKI SERVICE MANUAL".

6. SPECIFICATION CODE

This catalogue contains the parts for the model designed for the following spec. ;

spec. code : DF8A (R) : P1 DF9.9A (R) : P1

7. MODEL NAME AND ENGINE NUMBER

MODEL	YEAR'S	TYPE	TRANSOM	ENGINE NO.
DF8ALK10	'10	00801F	S, L	00801F-010001~
DF8ARLK10	'10	00801F	S, L	00801F-010001~
DF8AL		00801F	S, L	00801F-110001~
DF8ARL		00801F	S, L	00801F-110001~
DF9.9ALK10	'10	00994F	S, L	00994F-010001~
DF9.9ARLK10	'10	00994F	S, L	00994F-010001~
DF9.9AL		00994F	S, L	00994F-110001~
DF9.9ARL		00994F	S, L	00994F-110001~


DF8A/9.9A P1

- 3 -

PP005931.TIF DF8ALK11(P1) K11 2011 / * COLOR CHART *

DF8A/9.9A P1	0EP SHADOW BLACK METALLIC
DF8A/9.9A P1	13L BRIGHT SILVER METALLIC

DP005688.TIF DF8ALK11(P1) K11 2011 / CYLINDER HEAD


FIG.1DF8A 9.9A P01_001
CYLINDER HEAD

Part List

DP005688.TIF DF8ALK11(P1) K11 2011 / CYLINDER HEAD

REF NO	PART NO	DESCRIPTION	QTY	KIT	NOTES
1	11110-99J00-000	HEAD, CYLINDER	1		
2	11141-99J00-000	GASKET, CYLINDER HEAD	1		
3	11118-99J00-000	BOLT, NO.1 (8X67)	2		
3	11118-99JL0-000	BOLT, NO.1 (8X67)	2		DF8A:110001~, DF9.9A:110001~
4	11119-99J00-000	BOLT, NO.2 (8X77)	4		
4	11119-99JL0-000	BOLT, NO.2 (8X77)	4		DF8A:110001~, DF9.9A:110001~
5	01550-06257-000	BOLT, NO.3	3		
6	11216-90J00-000	GASKET.OIL GALLERY PLUG	1		
7	09248-22002-000	PLUG	1		
8	11261-93J00-000	COVER, PROTECTION ANODE	1		
9	09280-22019-000	O RING, PROTECTION COVER (D:1.9 ID:21.8)	1		
10	55321-87J00-000	ANODE, PROTECTION	1		
11	09103-06281-000	BOLT, PROTECTION ANODE	1		
12	01550-08207-000	BOLT, PROTECTION COVER	1		
13	11382-93E00-000	CAP, OIL FILLER	1		
14	09280-17003-000	O RING, OIL FILLER CAP (D:3.1 ID:16.8)	1		
15	04211-09109-000	PIN	2		
16	11170-99J00-000	COVER, CYLINDER HEAD	1		
17	11178-99J00-000	O RING, CYLINDER HEAD COVER	1		
18	01550-06207-000	BOLT, CYLINDER HEAD COVER	4		
19	11196-99J00-000	HOSE, BREATHER	1		
20	11173-99J00-000	PLATE, BREATHER	1		
21	01550-0612A-000	BOLT, BREATHER PLATE	4		
22	09482-00528-000	PLUG, SPARK (CR6E)	2		
22	09482-00L01-000	PLUG, SPARK (CR6E)	2		DF8A:110001~, DF9.9A:110001~
23	11115-09G00-001	GUIDE, VALVE (OS)	4		OPT

DP005689.TIF DF8ALK11(P1) K11 2011 / CYLINDER BLOCK

FIG.2


DF8A 9.9A P01_002
CYLINDER BLOCK

Part List

DP005689.TIF DF8ALK11(P1) K11 2011 / CYLINDER BLOCK

REF NO	PART NO	DESCRIPTION	QTY	KIT	NOTES
1	11301-99J00-000	BLOCK ASSY, CYLINDER	1		
2	01560-08557-000	BOLT	6	*	
3	04211-09109-000	PIN	2	*	
4	16440-11D00-000	REGULATOR ASSY, ENGINE	1		
4	16440-94JL0-000	REGULATOR ASSY, ENGINE	1		DF8A:110001~, DF9.9A:110001~
5	09403-12406-000	CLAMP	1		
6	01550-06127-000	BOLT, FUEL HOSE CLAMP	1		

DP005677.TIF DF8ALK11(P1) K11 2011 / CRANKSHAFT

FIG.3


DF8A 9.9A P01_003
CRANKSHAFT

Part List

DP005677.TIF DF8ALK11(P1) K11 2011 / CRANKSHAFT

REF NO	PART NO	DESCRIPTION	QTY	KIT	NOTES
1	12111-99J00-0B0	PISTON	2		
2	12140-99J00-000	RING SET, PISTON	2		
3	12151-99J00-000	PIN, PISTON	2		
4	09381-14001-000	CIRCLIP	4		
5	12160-99J00-000	CONNROD ASSY	1		
6	12163-99J00-000	BOLT, CONNROD	2	*	
7	04221-03059-000	PIN	2	*	
8	12220-99J00-000	CRANKSHAFT	1		
9	12341-99J00-000	BEARING, CRANKSHAFT	4		
10	09283-30075-000	SEAL, CRANKSHAFT OIL	2		
11	12100-99J00-050	PISTON SET (OS:0.50)	2		OPT

DP005681.TIF DF8ALK11(P1) K11 2011 / TIMING BELT

FIG.4


DF8A 9.9A P01_004
TIMING BELT

Part List

DP005681.TIF DF8ALK11(P1) K11 2011 / TIMING BELT

REF NO	PART NO	DESCRIPTION	QTY	KIT	NOTES
1	12631-99J00-000	PULLEY, CRANKSHAFT	1		
2	12635-99J00-000	GUIDE, TIMING BELT (UPPER)	1		
3	12636-99J00-000	GUIDE, TIMING BELT (LOWER)	1		
4	12637-99J00-000	NUT, TIMING PULLEY (M24)	1		
5	12638-99J00-000	WASHER, PULLEY NUT LOCK	1		
6	12741-93E01-000	PULLEY, CAMSHAFT	1		
7	09103-06267-000	BOLT, CAMSHAFT PULLEY (6X18)	1		
8	09160-06150-000	WASHER, CAMSHAFT PULLEY (6.5X24X4)	1		
9	08341-31039-000	KEY, CRANKSHAFT PULLEY	1		
10	08341-31039-000	KEY, CAMSHAFT PULLEY	1		
11	12625-99J00-000	BASE, STATOR	1		ELECTRIC STARTER
11	12625-99J10-000	BASE, STATOR	1		MANUAL STARTER
12	04211-09149-000	DOWEL PIN, STATOR BASE	2		
13	01550-06307-000	BOLT, STATOR BASE NO.1	3		
14	01550-08307-000	BOLT, STATOR BASE NO.3	1		ELECTRIC STARTER
15	01550-06127-000	BOLT, CLAMP	1		MANUAL STARTER
16	12761-99J00-000	BELT, TIMING	1		
17	12764-99J00-000	COVER, TIMING BELT	1		
18	09308-08011-000	GROMMET, TIMING BELT COVER	2		
19	61493-99J00-000	LABEL, CLEARANCE	1		
20	61494-99J00-000	LABEL, OIL	1		

DP005663.TIF DF8ALK11(P1) K11 2011 / CAMSHAFT

FIG.5


DF8A 9.9A P01_005
CAMSHAFT

Part List

DP005663.TIF DF8ALK11(P1) K11 2011 / CAMSHAFT

REF NO	PART NO	DESCRIPTION	QTY	KIT	NOTES
1	12700-99J00-000	CAMSHAFT ASSY	1		MANUAL STARTER, W/DECOMP
1	12711-99J10-000	CAMSHAFT	1		ELECTRIC STARTER, TYPE:R, N/DECOMP
2	09283-21009-000	SEAL, CAMSHAFT OIL (19.7X33X6) (19.7X33X6)	1		
3	12840-99J00-000	ARM, ROCKER	4		
4	12842-49201-000	SCREW, TAPPET ADJUSTING	4	*	
5	12843-27A00-000	NUT, TAPPET ADJUSTING	4	*	
6	12843-99J00-000	SPACER, ROCKER ARM (13X18X9)	2		
7	12861-99J00-000	SHAFT, ROCKER ARM (9X13X142.5)	1		
8	12891-99J00-000	SPRING, ROCKER SHAFT	1		
9	09164-13008-000	WASHER, WAVE	1		
10	12911-99J00-000	VALVE, INTAKE	2		
11	12915-99J00-000	VALVE, EXHAUST	2		
12	12921-99J00-000	SPRING, VALVE	4		
13	12931-09420-000	RETAINER, VALVE SPRING	4		
14	12932-27A00-000	COTTER, VALVE	8		
14	12932-09G00-000	COTTER, VALVE	8		DF8A:110001~, DF9.9A:110001~
15	12933-71C00-000	SEAT, VALVE SPRING	4		
16	09289-05008-000	SEAL, VALVE STEM	4		

DP005666.TIF DF8ALK11(P1) K11 2011 / INLET MANIFOLD

FIG.6


DF8A 9.9A P01_006
INLET MANIFOLD

Part List

DP005666.TIF DF8ALK11(P1) K11 2011 / INLET MANIFOLD

REF NO	PART NO	DESCRIPTION	QTY	KIT	NOTES
1	13111-99J00-000	MANIFOLD, INLET	1		
2	13119-99J00-000	GASKET, INLET MANIFOLD	1		
3	01550-06457-000	BOLT	3		
4	04221-05109-000	PIN, INLET MANIFOLD KNOCK	2		
5	13810-99J00-000	SILENCER	1		
6	13710-99J00-000	ARRESTER, FLAME	1		
7	09180-06290-000	SPACER	2		
8	13832-94J00-000	SEAL, SILENCER	1		
9	09169-06082-000	SPACER	1		
10	01550-06167-000	BOLT, SILENCER	1		

DP005695.TIF DF8ALK11(P1) K11 2011 / CARBURETOR

FIG.7

DF8A 9.9A P01_007
CARBURETOR


Part List

DP005695.TIF DF8ALK11(P1) K11 2011 / CARBURETOR

REF NO	PART NO	DESCRIPTION	QTY	KIT	NOTES
1	13200-99J00-000	CARBURETOR ASSY	1		DF8A MANUAL STARTER
1	13200-99J10-000	CARBURETOR ASSY	1		DF8A ELECTRIC STARTER, DF8A TYPE:R
1	13200-99J20-000	CARBURETOR ASSY	1		DF9.9A MANUAL STARTER
1	13200-99J30-000	CARBURETOR ASSY	1		DF9.9A ELECTRIC STARTER, DF9.9A TYPE:R
1	13200-99JL0-000	CARBURETOR ASSY	1		DF8A MANUAL STARTER, DF8A:110001~
1	13200-99JM0-000	CARBURETOR ASSY	1		DF8A ELECTRIC STARTER, DF8A TYPE:R, DF8A:110001~
1	13200-99JN0-000	CARBURETOR ASSY	1		DF9.9A MANUAL STARTER, DF9.9A:110001~
1	13200-99JP0-000	CARBURETOR ASSY	1		DF9.9A ELECTRIC STARTER, DF9.9A TYPE:R, DF9.9A:110001~
2	13236-99J00-000	NOZZLE, MAIN	1	*	DF8A
2	13236-99J20-000	NOZZLE, MAIN	1	*	DF9.9A
3	09491-70020-000	JET, MAIN (70)	1	*	DF8A
3	09491-82013-000	JET, MAIN (82)	1	*	DF9.9A
3	09491-68008-000	JET, MAIN (68)	1	*	OPT,DF8A
3	09491-80017-000	JET, MAIN (80)	1	*	OPT,DF9.9A
4	09492-38011-000	JET, PILOT (38)	1	*	
4	09492-35033-000	JET, PILOT (35)	1	*	OPT
5	13239-94J00-000	CAP, RUBBER	1	*	
6	13250-99J00-000	FLOAT	1	*	
7	13370-94J00-000	VALVE, FLOAT	1	*	
8	13247-94J00-000	SCREW	4	*	
9	13375-26E00-000	CLIP	1	*	
10	13254-94J00-000	PIN, ARM	1	*	
11	13802-94J00-000	SCREW	1	*	
12	13534-94J00-000	SCREW, STOP	1	*	
13	13268-94J00-000	SPRING	1	*	
14	13251-99J00-000	GASKET, FLOAT CHAMBER	1	*	
15	13240-99J00-000	CHAMBER ASSY, FLOAT	1	*	DF8A MANUAL STARTER, INC.NO.14,16,17
15	13240-99J10-000	CHAMBER ASSY, FLOAT	1	*	DF8A ELECTRIC STARTER, DF8A TYPE:R, INC.NO.14,16,17
15	13240-99J20-000	CHAMBER ASSY, FLOAT	1	*	DF9.9A MANUAL STARTER, INC.NO.14,16,17,33~35
15	13240-99J30-000	CHAMBER ASSY, FLOAT	1	*	DF9.9A ELECTRIC STARTER, DF9.9A TYPE:R, INC.NO.14,16,17,33~35
16	13279-99J00-000	SCREW, DRAIN	1	*	
17	13275-99J00-000	WASHER, PLANE	1	*	
18	13283-99J00-000	PACKING	1	*	
19	13282-99J00-000	PLATE	1	*	
20	13367-94J00-000	SCREW	3	*	
21	13361-99J00-000	HOLDER, CABLE	1	*	MANUAL STARTER
22	13362-94J00-000	GUIDE, CABLE	1	*	MANUAL STARTER

	000				
23	13363-94J00-000	CAP, CABLE SEALING	1	*	MANUAL STARTER
24	13364-94J00-000	VALVE, STARTER	1	*	MANUAL STARTER
25	13365-94J00-000	SPRING	1	*	MANUAL STARTER
26	13295-14G00-000	O RING	1	*	MANUAL STARTER
27	13428-06F30-000	PLATE	1	*	ELECTRIC STARTER, TYPE:R
28	13367-94J00-000	SCREW	1	*	ELECTRIC STARTER, TYPE:R
29	13368-99J00-000	STARTER ASSY	1	*	ELECTRIC STARTER, TYPE:R
30	13494-94J00-000	CLIP	1	*	DF9.9A
31	13495-94J00-000	CAP, RUBBER	1	*	DF9.9A
32	13496-99J00-000	ROD, LINK	1	*	DF9.9A
33	13493-99J00-000	PLUNGER	1	*	DF9.9A
34	13441-99J00-000	SPRING	1	*	DF9.9A
35	13443-99J00-000	SCREW, SPECIAL	1	*	DF9.9A
36	13281-99J00-000	SCREW, PAN	1	*	
37	09103-06276-000	BOLT (6X100)	2		
38	13125-99J00-000	GASKET, CARBURETOR	1		
39	13124-99J00-000	INSULATOR	1		
40	13436-91J00-000	CONNECTOR, THROTTLE ROD	1		
41	13513-99J00-000	ROD, THROTTLE	1		
42	13640-99J00-000	KNOB ASSY, STARTER	1		MANUAL STARTER
43	09159-14014-000	NUT, STARTER KNOB	1		MANUAL STARTER
44	09320-10501-000	CUSHION, STARTER KNOB	1		MANUAL STARTER

DP005967.TIF DF8ALK11(P1) K11 2011 / FUEL PUMP

FIG.8


DF8A 9.9A P01_008
FUEL PUMP

Part List

DP005967.TIF DF8ALK11(P1) K11 2011 / FUEL PUMP

REF NO	PART NO	DESCRIPTION	QTY	KIT	NOTES
1	15410-98500-000	FILTER, FUEL	1		
2	01550-06257-000	BOLT	2		
3	09280-26005-000	O RING (D:2.4 ID:26.2)	1		
3	09280-26L01-000	O RING (D:2.4 ID:26.2)	1		DF8A:110001~, DF9.9A:110001~
4	15192-99J00-000	HOSE, FUEL (CONN TO FILTER)	1		
4	15192-99J11-000	HOSE, FUEL (CONN TO FILTER)	1		DF8A:110001~, DF9.9A:110001~
5	15193-99J00-000	HOSE, FUEL (FILTER TO PUMP)	1		
5	15193-99J11-000	HOSE, FUEL (FILTER TO PUMP)	1		DF8A:110001~, DF9.9A:110001~
6	15191-99J00-000	HOSE, FUEL (PUMP TO CARB)	1		
6	15191-99J11-000	HOSE, FUEL (PUMP TO CARB)	1		DF8A:110001~, DF9.9A:110001~
7	09401-09404-000	CLIP	5		
8	09401-11422-000	CLIP	1		
9	09408-00054-000	CLAMP	1		
10	15100-94J0V-000	PUMP ASSY, FUEL	1		
10	15100-94JL0-000	PUMP ASSY, FUEL	1		DF8A:110001~, DF9.9A:110001~
11	15170-94J0V-000	DIAPHRAGM SET	1	*	
12	15251-93E00-000	SCREW	6	*	
13	15131-99J00-000	ROD, FUEL PUMP	1		
14	09403-12406-000	CLAMP	1		
15	01550-06127-000	BOLT, FUEL HOSE CLAMP	1		
16	18498-99J00-000	PROTECTOR, FUEL HOSE (100)	1		DF8A:110001~, DF9.9A:110001~

DP005658.TIF DF8ALK11(P1) K11 2011 / WATER PUMP


FIG.9DF8A 9.9A P01_009
WATER PUMP

Part List

DP005658.TIF DF8ALK11(P1) K11 2011 / WATER PUMP

REF NO	PART NO	DESCRIPTION	QTY	KIT	NOTES
1	17411-94J00-000	CASE, WATER PUMP	1		
2	17413-94J00-000	SLEEVE, WATER PUMP CASE	1		
3	17461-93903-000	IMPELLER, WATER PUMP	1		
3	17461-939L0-000	IMPELLER, WATER PUMP	1		DF8A:110001~, DF9.9A:110001~
4	17471-99J00-000	PANEL, PUMP CASE UNDER	1		
5	17472-99J00-000	GASKET, PUMP CASE PANEL	1		
6	17473-94J00-000	GASKET, WATER PUMP CASE	1		
7	17561-99J00-000	TUBE, WATER (S)	1		
7	17561-99J10-000	TUBE, WATER (L)	1		
8	17563-94J00-000	GROMMET, WATER TUBE	1		
9	17564-99J00-000	BUSH, WATER PUMP CASE	1		
10	17631-99J10-000	FILTER, WATER PORT SIDE	1		
11	17632-99J10-000	FILTER, WATER STBD SIDE	1		
12	03141-0416A-000	SCREW, WATER FILTER	1		
13	23118-94J00-000	NUT, WATER PUMP CASE (M6)	4		
14	09108-06141-000	BOLT, STUD	4		
15	09160-06082-000	WASHER, WATER PUMP CASE (6.5X13X1)	4		
16	09420-03005-000	KEY	1		
17	09202-04008-000	PIN, WATER PUMP KNOCK (4X9)	2		
18	17400-99J00-000	KIT, WATER PUMP REPAIR	1		OPT, ĩł½Ú»ĭł½Ê, 3~6,16 ĩł½b¹.

DP005656.TIF DF8ALK11(P1) K11 2011 / THERMOSTAT

FIG.10


DF8A 9.9A P01_010
THERMOSTAT

Part List

DP005656.TIF DF8ALK11(P1) K11 2011 / THERMOSTAT

REF NO	PART NO	DESCRIPTION	QTY	KIT	NOTES
1	17670-94J00-000	THERMOSTAT (60 $\pm$ ½C)	1		
2	17681-99J00-000	COVER, THERMOSTAT	1		
3	01550-08307-000	BOLT	2		
4	11197-99J00-000	HOSE, WATER RETURN	1		
5	09401-12413-000	CLIP	2		
6	09408-00173-000	CLAMP	1		
7	11291-91B50-000	HOOK, ENGINE	1		OPT
8	01550-08207-000	BOLT	1		OPT

DP005692.TIF DF8ALK11(P1) K11 2011 / RECOIL STARTER


FIG.11DF8A 9.9A P01_011
RECOIL STARTER

Part List

DP005692.TIF DF8ALK11(P1) K11 2011 / RECOIL STARTER

REF NO	PART NO	DESCRIPTION	QTY	KIT	NOTES
1	18100-99J00-000	STARTER ASSY, RECOIL	1		
2	18120-99J00-000	REEL	1	*	
3	18130-99J00-000	RATCHET SET	1	*	
4	18142-98600-000	SPRING, SPIRAL	1	*	
5	18181-99J00-000	GUIDE, ROPE	1	*	
6	18210-99J00-000	GRIP ASSY	1	*	
7	18280-99J00-000	NSI SET	1	*	
8	99000-81158-50M	ROPE	1		
9	18193-99J00-000	SEAL, RECOIL STARTER	1		
10	01550-06307-000	BOLT	3		
11	18290-99J00-000	CABLE ASSY, NSI	1		
12	03542-06129-000	SCREW	2		
13	37726-99J00-000	BRACKET, NSI CABLE	1		
14	01550-06167-000	BOLT	2		
15	69711-93E10-000	LABEL (S.I.G.P.)	1		
16	61472-93E00-000	LABEL, RECOIL STARTER	1		
16	61472-94J10-000	LABEL, RECOIL STARTER	1		DF8A:010867~, DF9.9A:011403~

DP005659.TIF DF8ALK11(P1) K11 2011 / THROTTLE CONTROL (EXCEPT TYPE:R)

FIG.12DF8A 9.9A P01_012
THROTTLE CONTROL (EXCEPT TYPE:R)

Part List

DP005659.TIF DF8ALK11(P1) K11 2011 / THROTTLE CONTROL (EXCEPT TYPE:R)


REF NO	PART NO	DESCRIPTION	QTY	KIT	NOTES
1	19120-99J00-000	DRUM, THROTTLE CONTROL	1		
2	19131-95502-000	CONNECTOR, THROTTLE ROD	2		
3	19148-99J00-000	LEVER, INTERLINK THROTTLE NO.1	1		
4	19184-99J00-000	BRACKET, THROTTLE CABLE	1		
5	19656-99J00-000	ROD, THROTTLE	1		
6	19810-99J00-000	STOPPER, THROTTLE	1		
7	09140-05005-000	NUT, THROTTLE STOPPER ROD	2		
8	09160-06046-000	WASHER, THROTTLE LINK (6.5X20X1.5)	1		
9	09160-06046-000	WASHER, THROTTLE STOPPER (6.5X20X1.5)	2		
10	09180-06186-000	SPACER, THROTTLE LINK NO.1 (6.2X12.6X21)	1		
11	09180-06230-000	SPACER, THROTTLE STOPPER (6.2X12.6X12.5)	1		
12	09180-12158-000	SPACER, THROTTLE LINK NO.2 (12.2X20X19.9)	1		
13	01550-06167-000	BOLT, THROTTLE CABLE BRACKET	1		
14	01550-06307-000	BOLT, THROTTLE STOPPER	1		
15	01550-06357-000	BOLT, THROTTLE LINK	1		

Page Notes

DP005659.TIF DF8ALK11(P1) K11 2011 / THROTTLE CONTROL (EXCEPT TYPE:R)

NOTE TEXT
OEM: REFER TO FIG.13(C- 6) FOR TYPE:R

DP005654.TIF DF8ALK11(P1) K11 2011 / THROTTLE CONTROL (TYPE:R)

FIG.13


DF8A 9.9A P01_013
THROTTLE CONTROL (TYPE:R)

Part List

DP005654.TIF DF8ALK11(P1) K11 2011 / THROTTLE CONTROL (TYPE:R)

REF NO	PART NO	DESCRIPTION	QTY	KIT	NOTES
1	19120-99J10-000	LEVER, THROTTLE CONTROL	1		
2	19122-99J00-000	LEVER, INTERLINK THROTTLE NO.2	1		
3	19148-99J10-000	LEVER, INTERLINK THROTTLE NO.1	1		
4	19184-99J10-000	PLATE, THROTTLE LINK	1		
5	19185-99J00-000	SPRING, THROTTLE LEVER	1		
6	09160-06046-000	WASHER, THROTTLE LINK (6.5X20X1.5)	1		
7	09180-06186-000	SPACER, THROTTLE LINK NO.1 (6.2X12.6X21)	1		
8	01550-06167-000	BOLT, THROTTLE CABLE BRACKET	1		
9	01550-06357-000	BOLT, THROTTLE LINK	1		

DP005955.TIF DF8ALK11(P1) K11 2011 / OIL PUMP


FIG.14DF8A 9.9A P01_014
OIL PUMP

Part List

DP005955.TIF DF8ALK11(P1) K11 2011 / OIL PUMP

REF NO	PART NO	DESCRIPTION	QTY	KIT	NOTES
1	16400-99J00-000	PUMP ASSY, OIL	1		
1	16400-99JL0-000	PUMP ASSY, OIL	1		DF8A:110001~, DF9.9A:110001~
2	16542-99J00-000	GASKET, OIL PUMP	1		
3	09261-03009-000	PIN (3X15.8)	1		
4	01550-06357-000	BOLT	3		
5	16510-05240-000	FILTER, ENGINE OIL	1		
5	16510-45H10-000	FILTER, ENGINE OIL	1		DF8A:110001~, DF9.9A:110001~
6	16512-99J00-000	CAP, OIL FILTER	1		
7	09280-13004-000	O RING (D:1.9 ID:13)	1		
8	09280-54001-000	O RING (D:2.4 ID:52.6)	1		
9	09440-18002-000	SPRING	1		
10	01550-06207-000	BOLT	3		
11	01550-06127-000	BOLT	1		
12	16910-99J00-000	GAUGE, OIL LEVEL	1		
13	16930-99J00-000	GUIDE, OIL LEVEL GAUGE	1		
14	09280-10016-000	O RING (D:1.9 ID:9.8)	1		
14	09280-10L01-000	O RING (D:1.9 ID:9.8)	1		DF8A:110001~, DF9.9A:110001~

DP005665.TIF DF8ALK11(P1) K11 2011 / CLUTCH ROD (EXCEPT TYPE:R)

FIG.15

DF8A 9.9A P01_015
CLUTCH ROD (EXCEPT TYPE:R)

Part List

DP005665.TIF DF8ALK11(P1) K11 2011 / CLUTCH ROD (EXCEPT TYPE:R)


REF NO	PART NO	DESCRIPTION	QTY	KIT	NOTES
1	21122-99J00-000	PLATE, CLUTCH NOTCH	1		
2	09160-06082-000	WASHER, NOTCH SPRING (6.5X13X1)	1		
3	09260-10006-000	BALL, CLUTCH NOTCH	1		
4	09381-14004-000	CIRCLIP, NOTCH SPRING	1		
5	09440-07079-000	SPRING, CLUTCH NOTCH	1		
6	02112-06127-000	SCREW, NOTCH PLATE	2		
7	21126-99J00-000	HOLDER, CLUTCH SHAFT	1		
8	01550-06167-000	BOLT, HOLDER	2		
9	21210-99J00-000	SHAFT, CLUTCH LEVER	1		
10	23111-99J00-000	ROD, CLUTCH (S)	1		
10	23111-99J10-000	ROD, CLUTCH (L)	1		
11	23131-99J00-000	BOOT, CLUTCH ROD	1		
12	09383-04002-000	E RING	1		
13	21127-99J00-000	BRACKET, SHIFT CABLE	1		
14	01550-06167-000	BOLT, SHIFT CABLE BRACKET	2		
15	21212-99J00-000	DRUM, SHIFT	1		
16	23115-99J00-000	LINK, SHIFT DRUM	1		

Page Notes

DP005665.TIF DF8ALK11(P1) K11 2011 / CLUTCH ROD (EXCEPT TYPE:R)

NOTE TEXT
OEM: REFER TO FIG.16(D- 3) FOR TYPE:R

DP005664.TIF DF8ALK11(P1) K11 2011 / CLUTCH ROD (TYPE:R)

FIG.16

DF8A 9.9A P01_016
CLUTCH ROD (TYPE:R)


Part List

DP005664.TIF DF8ALK11(P1) K11 2011 / CLUTCH ROD (TYPE:R)

REF NO	PART NO	DESCRIPTION	QTY	KIT	NOTES
1	21122-99J00-000	PLATE, CLUTCH NOTCH	1		
2	09160-06082-000	WASHER, NOTCH SPRING (6.5X13X1)	1		
3	09260-10006-000	BALL, CLUTCH NOTCH	1		
4	09381-14004-000	CIRCLIP, NOTCH SPRING	1		
5	09440-07079-000	SPRING, CLUTCH NOTCH	1		
6	02112-06127-000	SCREW, NOTCH PLATE	2		
7	21126-99J00-000	HOLDER, CLUTCH SHAFT	1		
8	01550-06167-000	BOLT, HOLDER	2		
9	21210-99J00-000	SHAFT, CLUTCH LEVER	1		
10	23111-99J00-000	ROD, CLUTCH (S)	1		
10	23111-99J10-000	ROD, CLUTCH (L)	1		
11	23131-99J00-000	BOOT, CLUTCH ROD	1		
12	09383-04002-000	E RING	1		
13	21241-99J00-000	LINK, CLUTCH LEVER	1		
14	23210-99J00-000	LEVER, CLUTCH CONTROL	1		
15	09204-01002-000	PIN, CLUTCH LEVER LINK	1		
16	09160-05029-000	WASHER, CL LINK LEVER (5.5X12X0.8)	2		
17	09385-04003-000	CLIP, CL LEVER LINK	1		

DP005652.TIF DF8ALK11(P1) K11 2011 / SHIFT ROD

FIG.17



DF8A 9.9A P01_017
SHIFT ROD

Part List

DP005652.TIF DF8ALK11(P1) K11 2011 / SHIFT ROD


REF NO	PART NO	DESCRIPTION	QTY	KIT	NOTES
1	23311-95J00-000	CONNECTOR, CLUTCH ROD	1		
2	25111-99J00-000	ROD, SHIFT	1		
3	25311-99J00-000	CAM, SHIFT	1		
4	09205-02004-000	PIN, SHIFT ROD SPRING	2		
5	25211-99J00-000	GUIDE, SHIFT ROD	1		
6	25215-99J00-000	STOPPER, SHIFT ROD GUIDE	1		
7	29141-93J00-000	NUT, CLUTCH ROD (M6)	1		
8	09160-06082-000	WASHER, SHIFT ROD GUIDE (6.5X13X1)	1		
9	09280-06012-000	O RING, SHIFT ROD (D:1.7 ID:5.5)	2		
10	09280-09012-000	O RING, SHIFT ROD GUIDE (D:2.3 ID:9)	1		
11	09289-06164-000	SEAL, SHIFT ROD DUST	1		

Part List

DP005672.TIF DF8ALK11(P1) K11 2011 / TRANSMISSION

REF NO	PART NO	DESCRIPTION	QTY	KIT	NOTES
1	57100-99J20-000	SHAFT ASSY, DRIVE (S)	1		
1	57100-99J30-000	SHAFT ASSY, DRIVE (L)	1		
2	08110-60020-000	BEARING	1	*	
3	09380-15001-000	CIRCLIP	2	*	
4	09160-20027-000	WASHER (20X35X2.75)	1		
5	09181-20251-000	SHIM (20X34X1.0)	1		PINION
5	09160-20042-000	SHIM (20X34X1.1)	1		
5	09160-20043-000	SHIM (20X34X1.2)	1		
5	09160-20044-000	SHIM (20X34X1.3)	1		
5	09181-20244-000	SHIM (20X34X0.7)	1		
5	09181-20246-000	SHIM (20X34X0.8)	1		
5	09181-20248-000	SHIM (20X34X0.9)	1		
6	09160-21009-000	WASHER (21X35X2.75)	1		PINION THRUST UPR
7	09263-20024-000	BEARING (20X35X4.5)	1		PINION THRUST
8	57311-94J00-000	PINION	1		
9	57510-94J00-000	GEAR, FORWARD	1		
10	57521-94J00-000	GEAR, REVERSE	1		
11	09160-17024-000	WASHER (17X23X1.1)	1		PROP SHAFT REV
11	09160-17039-000	WASHER (17X23X1.2)	1		
11	09160-17025-000	WASHER (17X23X1.3)	1		
11	09160-17040-000	WASHER (17X23X1.4)	1		
11	09160-17026-000	WASHER (17X23X1.5)	1		
11	09160-17041-000	WASHER (17X23X1.6)	1		
11	09160-17027-000	WASHER (17X23X1.7)	1		
11	09160-17042-000	WASHER (17X23X1.8)	1		
11	09160-17028-000	WASHER (17X23X1.9)	1		
12	09181-25160-000	SHIM (25X34X0.7)	2		BACK UP
12	09181-25162-000	SHIM (25X34X0.8)	2		
12	09181-25164-000	SHIM (25X34X0.9)	2		
12	09160-25040-000	SHIM (25X34X1.0)	2		
12	09160-25041-000	SHIM (25X34X1.1)	2		
12	09160-25042-000	SHIM (25X34X1.2)	2		
12	09181-25181-000	SHIM (25X34X1.3)	2		
13	09181-15156-000	WASHER (15X22X1.5)	1		PROP SHAFT FWD
14	57610-99J10-000	SHAFT, PROPELLER	1		
15	57621-93902-000	SHIFTER, CLUTCH DOG	1		
16	09202-04025-000	PIN (4X31)	1		
17	59441-94J00-000	SPRING, RETURN	1		
18	59441-99J00-000	SPRING, DOG	1		
19	57631-93901-000	ROD, PUSH	1		
20	57632-98500-000	PIN (6X6)	1		
21	56130-99J10-000	HOUSING, DRIVE SHAFT	1		
22	09282-13003-000	SEAL, DRIVE SHAFT OIL (12.5X25X7)	2	*	
23	56132-99J00-000	GASKET, DRIVE SHAFT BRG HSG	1		
24	09116-06121-000	BOLT, DRIVE SHAFT BRG HSG (6X25)	2		

DP005697.TIF DF8ALK11(P1) K11 2011 / STARTING MOTOR


FIG.19DF8A 9.9A P01_019
STARTING MOTOR

Part List

DP005697.TIF DF8ALK11(P1) K11 2011 / STARTING MOTOR

REF NO	PART NO	DESCRIPTION	QTY	KIT	NOTES
1	31100-94J21-000	STARTING MOTOR	1		
2	31131-94J00-000	BRUSH SET, PLUS	1	*	
3	31135-90J00-000	SPRING	4	*	
4	31151-94J00-000	CASE, GEAR	1	*	
5	31152-90J00-000	PLATE, CENTER	1	*	
6	31153-90J00-000	BRACKET, PLANET GEAR	1	*	
7	31171-96J00-000	COVER KIT, DUST	1	*	
8	31173-94J00-000	HOLDER ASSY, BRUSH	1	*	
9	31191-96J00-000	LEVER, SHIFT	1	*	
10	31220-94J00-000	SWITCH, MAGNET	1	*	
11	31310-90J00-000	ARMATURE	1	*	
12	31320-94J00-000	PINION	1	*	
13	31341-94J00-000	SHAFT, PINION	1	*	
14	31343-90J00-000	INTERNAL GEAR	1	*	
15	31344-90J00-000	GEAR, PLANETARY	3	*	
16	31360-93J01-000	WASHER SET	1	*	
17	31912-99J00-000	BAND, STARTING MOTOR	1		
18	31918-94J00-000	DAMPER, LOWER	1		
19	38860-76F01-000	RELAY, STARTING MOTOR	1		
20	38915-90J00-000	HOLDER, RELAY	1		
21	01550-06167-000	BOLT, LOWER	2		
22	01550-08257-000	BOLT, UPPER	2		
23	08316-10087-000	NUT	1		

DP005699.TIF DF8ALK11(P1) K11 2011 / MAGNETO


FIG.20DF8A 9.9A P01_020
MAGNETO

Part List

DP005699.TIF DF8ALK11(P1) K11 2011 / MAGNETO

REF NO	PART NO	DESCRIPTION	QTY	KIT	NOTES
1	32120-99J00-000	COIL, STATOR & PULSER	1		ELECTRIC STARTER, TYPE:R
2	09125-06035-000	SCREW, STATOR COIL (6X25)	3		ELECTRIC STARTER, TYPE:R
3	32120-99J10-000	COIL, BATTERY CHARGING	1		MANUAL STARTER
4	32140-99J10-000	COIL, EXITER / PULSER	1		MANUAL STARTER
5	02162-05127-000	SCREW, IGNITION TIMING COIL	2		
6	32102-99J00-000	FLYWHEEL	1		ELECTRIC STARTER, TYPE:R
6	32102-99J10-000	FLYWHEEL	1		MANUAL STARTER
7	09140-14008-000	NUT, MAGNETO FLYWHEEL (M14)	1		
8	09160-15047-000	WASHER, FLYWHEEL (15X27X4.0)	1		
9	08341-31039-000	KEY	1		
10	09407-14407-000	CLAMP, HARNESS	1		
11	09407-14403-000	CLAMP, STATOR LEAD	1		MANUAL STARTER
12	02112-06307-000	SCREW, MAGNETO COIL	4		MANUAL STARTER

DP005674.TIF DF8ALK11(P1) K11 2011 / RECTIFIER / IGNITION COIL

FIG.21


DF8A 9.9A P01_021
IGNITION COIL

Part List

DP005674.TIF DF8ALK11(P1) K11 2011 / RECTIFIER / IGNITION COIL

REF NO	PART NO	DESCRIPTION	QTY	KIT	NOTES
1	32800-99J00-000	RECTIFIER/REGULATOR ASSY	1		ELECTRIC STARTER, TYPE:R
2	01550-06257-000	BOLT	2		ELECTRIC STARTER, TYPE:R
3	32890-99J00-000	HOLDER, ELECTRIC PARTS	1		
4	09160-06084-000	WASHER, ELECTRIC PARTS HOLDER (6.5X18X1.6)	2		
5	09169-06062-000	WASHER, ELECTRIC PARTS HOLDER	2		
6	09320-09016-000	CUSHION, ELECTRIC PARTS HOLDER	2		
7	01550-06257-000	BOLT, ELECTRIC PARTS HOLDER	2		
8	32900-99J00-000	CDI UNIT	1		ELECTRIC STARTER, TYPE:R
8	32900-99J10-000	CDI UNIT	1		MANUAL STARTER
9	32980-99J00-000	CUSHION, CDI	1		
10	33500-07H00-000	CAP, SPARK PLUG	2		
11	33410-99J00-000	COIL, IGNITION	1		
12	01550-06257-000	BOLT	2		
13	33833-94JL0-000	TUBE, IGN COIL LEAD (L:120)	1		
14	33833-94J10-000	PROTECTOR, HIGH TENSION (L:50)	1		ELECTRIC STARTER, TYPE:R
15	09407-14407-000	CLAMP, PROTECTOR	1		ELECTRIC STARTER, TYPE:R

DP005657.TIF DF8ALK11(P1) K11 2011 / SENSOR / SWITCH


FIG.22DF8A 9.9A P01_022
SENSOR/SWITCH

Part List

DP005657.TIF DF8ALK11(P1) K11 2011 / SENSOR / SWITCH

REF NO	PART NO	DESCRIPTION	QTY	KIT	NOTES
1	34830-87J20-000	SENSOR ASSY, TEMP	1		
2	37820-93E10-000	SWITCH ASSY, OIL PRESSURE	1		
3	36360-99J00-000	INDICATOR, OIL PRESSURE	1		EXCEPT TYPE:R
3	36360-99J10-000	INDICATOR, OIL PRESSURE	1		TYPE:R
4	36367-99J00-000	LABEL, WARNING	1		
5	37161-89E13-000	SWITCH ASSY, STARTER MOTOR	1		ELECTRIC STARTER
6	09159-14014-000	NUT	1		ELECTRIC STARTER
7	37721-99J10-000	SWITCH ASSY, NEUTRAL	1		ELECTRIC STARTER, TYPE:R
8	37724-99J00-000	ROD, SW PUSH	1		ELECTRIC STARTER, TYPE:R
9	37726-99J10-000	BRACKET, NEUTRAL SW	1		ELECTRIC STARTER, TYPE:R
10	09137-04004-000	SCREW, NEUTRAL SW BRKT (4X16)	1		ELECTRIC STARTER, TYPE:R
11	33833-99J00-000	TUBE, SW LEAD (L:80)	1		
12	09407-14407-000	CLAMP, SW LEAD	1		

DP005676.TIF DF8ALK11(P1) K11 2011 / HARNESS

FIG.23DF8A 9.9A P01_023
HARNESS


Part List

DP005676.TIF DF8ALK11(P1) K11 2011 / HARNESS

REF NO	PART NO	DESCRIPTION	QTY	KIT	NOTES
1	33810-99J00-000	CABLE, STARTER	1		ELECTRIC STARTER, TYPE:R
2	09407-14403-000	CLAMP, BATTERY CABLE	1		ELECTRIC STARTER
3	36610-99J00-000	HARNESS ASSY, WIRING	1		ELECTRIC STARTER
3	36610-99J10-000	HARNESS ASSY, WIRING	1		MANUAL STARTER
3	36610-99J20-000	HARNESS ASSY, WIRING	1		TYPE:R
4	09481-20501-000	FUSE (20A)	1	*	
5	36618-43410-000	CAP, OIL PRESSURE SWITCH	1	*	
6	36615-96300-000	TERMINAL, RESIN	1		EXCEPT TYPE:R
7	36656-99J00-000	GROMMET, CABLE (PORT)	1		EXCEPT TYPE:R
7	36656-99J10-000	GROMMET, CABLE (PORT)	1		TYPE:R
8	09403-13311-000	CLAMP, HARNESS	1		
9	09407-14403-000	CLAMP, HARNESS	1		
10	09408-00265-000	CLAMP, HARNESS	1		
11	33833-99J10-000	TUBE, HARNESS LEAD	1		ELECTRIC STARTER, TYPE:R
12	09407-14407-000	CLAMP, HARNESS	1		

DP005678.TIF DF8ALK11(P1) K11 2011 / CLAMP BRACKET (EXCEPT TYPE:R)

FIG.24



DF8A 9.9A P01_024
CLAMP BRACKET (EXCEPT TYPE:R)

Part List

DP005678.TIF DF8ALK11(P1) K11 2011 / CLAMP BRACKET (EXCEPT TYPE:R)


REF NO	PART NO	DESCRIPTION	QTY	KIT	NOTES
1	41111-99J00-0EP	BRACKET, CLAMP STBD	1		
2	41121-99J00-0EP	BRACKET, CLAMP PORT	1		
3	41211-99J00-000	SCREW, CLAMP	2		
3	41211-99JL0-000	SCREW, CLAMP	2		DF8A:110001~, DF9.9A:110001~
4	41212-91J00-000	HANDLE, CLAMP	2		
5	41213-98100-000	PLATE, CLAMP	2		
6	09205-06007-000	PIN (6.2X25)	2		
7	09100-10312-000	BOLT, CLAMP BRKT (10X146)	1		
8	09159-10050-000	NUT, CLAMP BRKT	1		
9	09160-10082-000	WASHER, CLAMP BRKT (10.5X19X2)	2		
10	09100-06125-000	BOLT, CLAMP BRKT LWR (6X140)	1		
11	09160-06082-000	WASHER, CLAMP BRKT LWR LOCK (6.5X13X1)	1		
12	09180-06357-000	SPACER, CLAMP BRKT LWR (6.5X10.5X104)	1		
13	23118-94J00-000	NUT, CLAMP BRKT LWR (M6)	1		
14	45261-94J00-000	LEVER, RELEASE	1		
15	09306-10023-000	BUSH, RELEASE LEVER	2		
16	09100-08239-000	BOLT, TRANSOM (8X90)	2		
17	09140-08023-XC0	NUT, TRANSOM BOLT	2		
18	09160-08081-000	WASHER, TRANSOM BOLT (8.5X23X1.5)	4		
19	29162-93J10-000	WASHER, TRANSOM BOLT LOCK	2		
20	41153-96300-000	CAP, TRANSOM BOLT	2		
21	45420-99J00-000	PIN, TILT LOCK	1		
22	45425-94J00-000	STOPPER, TILT LOCK PIN	1		
23	09441-17001-000	SPRING, TILT LOCK PIN	1		
24	45269-94J20-000	MARK, REVERSE LOCK	1		
25	69911-91J00-000	MARK, CLAMP BRACKET	1		
25	69911-91J40-000	MARK, CLAMP BRACKET	1		DF8A:010867~, DF9.9A:011403~
26	41210-99J00-000	SCREW SET, CLAMP	2		OPT, NOT SHOWN
26	41210-99JL0-000	SCREW SET, CLAMP	2		DF8A:110001~, DF9.9A:110001~

Page Notes

DP005678.TIF DF8ALK11(P1) K11 2011 / CLAMP BRACKET (EXCEPT TYPE:R)

NOTE TEXT
OEM: REFER TO FIG.25(F- 3) FOR TYPE:R

DP005682.TIF DF8ALK11(P1) K11 2011 / CLAMP BRACKET (TYPE:R)

FIG.25


DF8A 9.9A P01_025
CLAMP BRACKET (TYPE:R)

Part List

DP005682.TIF DF8ALK11(P1) K11 2011 / CLAMP BRACKET (TYPE:R)

REF NO	PART NO	DESCRIPTION	QTY	KIT	NOTES
1	41111-94J20-0EP	BRACKET, CLAMP STBD	1		
2	41121-94J20-0EP	BRACKET, CLAMP PORT	1		
3	41211-99J00-000	SCREW, CLAMP	2		
3	41211-99JL0-000	SCREW, CLAMP	1		DF8A:110001~, DF9.9A:110001~
4	41212-91J00-000	HANDLE, CLAMP	2		
5	41213-98100-000	PLATE, CLAMP	2		
6	09205-06007-000	PIN (6.2X25)	2		
7	41130-93E02-000	SHAFT, CLAMP BRKT	1		
8	09159-22006-000	NUT, CLAMP BRKT SHAFT	1		
9	41161-94400-000	SEAL, STEERING CABLE	1		
10	09100-06125-000	BOLT, CLAMP BRKT LWR (6X140)	1		
11	09160-06082-000	WASHER, CLAMP BRKT LWR LOCK (6.5X13X1)	1		
12	09180-06357-000	SPACER, CLAMP BRKT LWR (6.5X10.5X104)	1		
13	23118-94J00-000	NUT, CLAMP BRKT LWR (M6)	1		
14	45261-94J00-000	LEVER, RELEASE	1		
15	09306-22006-000	BUSH, RELEASE LEVER	2		
16	09100-08239-000	BOLT, TRANSOM (8X90)	2		
17	09140-08023-XC0	NUT, TRANSOM BOLT	2		
18	09160-08081-000	WASHER, TRANSOM BOLT (8.5X23X1.5)	4		
19	29162-93J10-000	WASHER, TRANSOM BOLT LOCK	2		
20	41153-96300-000	CAP, TRANSOM BOLT	2		
21	45420-99J00-000	PIN, TILT LOCK	1		
22	45425-94J00-000	STOPPER, TILT LOCK PIN	1		
23	09441-17001-000	SPRING, TILT LOCK PIN	1		
24	45269-94J20-000	MARK, REVERSE LOCK	1		
25	69911-91J00-000	MARK, CLAMP BRACKET	1		
25	69911-91J40-000	MARK, CLAMP BRACKET	1		DF8A:010867~, DF9.9A:011403~
26	41210-99J00-000	SCREW SET, CLAMP	2		OPT, NOT SHOWN
26	41210-99JL0-000	SCREW SET, CLAMP	2		DF8A:110001~, DF9.9A:110001~

DP005693.TIF DF8ALK11(P1) K11 2011 / SWIVEL BRACKET

FIG.26


DF8A 9.9A P01_026
SWIVEL BRACKET

Part List

DP005693.TIF DF8ALK11(P1) K11 2011 / SWIVEL BRACKET

REF NO	PART NO	DESCRIPTION	QTY	KIT	NOTES
1	22511-99011-000	NIPPLE	3		
2	43111-99J00-0EP	BRACKET, SWIVEL (S)	1		
2	43111-99J10-0EP	BRACKET, SWIVEL (L)	1		
3	43711-99J00-000	BUSH, STEERING	2		
4	43750-99J00-0EP	BRACKET, STEERING (S)	1		
4	43750-99J10-0EP	BRACKET, STEERING (L)	1		
4	43750-99J20-0EP	BRACKET, STEERING (S)	1		DF8A:110001~, DF9.9A:110001~
4	43750-99J30-0EP	BRACKET, STEERING (L)	1		DF8A:110001~, DF9.9A:110001~
5	09160-27009-000	WASHER, PILOT SHAFT (27.5X47X2)	2		
6	09282-27002-000	SEAL, STRG UNDER BUSH (26X39X5)	1		
7	43211-99J00-000	BUSH, SWIVEL BRACKET	2		EXCEPT TYPE:R
8	43211-87J00-000	BUSH, SWIVEL BRACKET	2		TYPE:R
8	43211-87JL0-000	BUSH, SWIVEL BRACKET	2		DF8A:110001~, DF9.9A:110001~
9	43755-99J00-000	ATTACHMENT, STRG BRKT	1		TYPE:R
10	09108-08286-000	BOLT, ATTACHMENT STUD	2		TYPE:R
11	09159-08059-000	NUT, ATTACHMENT (M8)	2		TYPE:R
12	09160-08082-000	WASHER, ATTACHMENT (8.5X16X1.2)	2		TYPE:R
13	41225-94502-000	PIN, RELEASE ARM	1		
14	45212-99J10-000	SPRING, REVERSE LOCK ARM	2		
15	45231-99J10-000	ARM, REVERSE LOCK	1		
16	45241-99J10-000	LINK, REVERSE LOCK ARM	1		
16	45241-99JL0-000	LINK, REVERSE LOCK ARM	1		DF8A:110001~, DF9.9A:110001~
17	09204-01002-000	PIN, CL LEVER LINK	1		
18	45247-99J00-000	PIN, REV LOCK ARM COTTER	1		
19	45250-94J00-000	LINK, RELEASE	1		
20	09200-06061-000	PIN, REV LOCK ARM LINK (L:95.5)	1		
21	09160-06082-000	WASHER, REV LOCK ARM LINK PIN (6.5X13X1)	1		
22	09200-05014-000	PIN, REV LOCK ARM (L:73)	1		
23	43411-93900-000	PLATE, STRG ADJUSTER	1		
24	43412-93900-000	COVER, STRG ADJUSTER	1		
25	43419-94J00-000	SPRING, STRG ADJUSTER	1		
26	09160-08082-000	WASHER, STRG ADJUSTER (8.5X16X1.2)	1		
27	09100-08232-000	BOLT, STRG ADJUSTER (8X30)	1		
28	43410-99J00-000	LEVER, STRG ADJ	1		EXCEPT TYPE:R
29	43412-99J00-000	COVER, STRG ADJ	1		EXCEPT TYPE:R
30	43415-99J00-000	PLATE, STRG ADJ	1		EXCEPT TYPE:R
31	43420-99J10-000	PLATE, ADJ FRICTION	1		EXCEPT TYPE:R
32	43424-99J00-000	HOLDER, ADJ NUT	1		EXCEPT TYPE:R
33	43427-99J00-000	SPACER, ADJ NUT	1		EXCEPT TYPE:R
34	43428-99J00-000	BUSH, ADJ NUT	1		EXCEPT TYPE:R
35	43512-99J00-000	SHAFT, ADJ THREAD	1		EXCEPT TYPE:R
36	43514-94J00-000	PLATE, ADJ FRICTION	1		EXCEPT TYPE:R
37	43514-99J00-000	WASHER, ADJ FRICTION PLATE	1		EXCEPT TYPE:R
38	43516-89J00-000	WASHER, STRG ADJ	2		EXCEPT TYPE:R
39	09116-06094-000	BOLT, ADJ PLATE	2		EXCEPT TYPE:R
40	09116-06121-000	BOLT, ADJ NUT HOLDER (6X25)	1		EXCEPT TYPE:R
41	09159-08059-000	NUT, ADJ UPPER (M8)	1		EXCEPT TYPE:R
42	45710-99J00-000	ARM, SHALLOW DRIVE	1		
42	45710-99JL0-000	ARM, SHALLOW DRIVE	1		DF8A:110001~, DF9.9A:110001~
43	45722-94J11-000	SPRING, ARM	1		
44	09111-10032-000	BOLT, ARM (10X16)	2		
45	45269-99J00-000	MARK, STRG ADJ	1		EXCEPT TYPE:R

DP005668.TIF DF8ALK11(P1) K11 2011 / ENGINE HOLDER


FIG.27DF8A 9.9A P01_027
ENGINE HOLDER

Part List

DP005668.TIF DF8ALK11(P1) K11 2011 / ENGINE HOLDER

REF NO	PART NO	DESCRIPTION	QTY	KIT	NOTES
1	51110-99J00-000	HOLDER, ENGINE	1		
2	51211-99J00-000	GASKET, ENGINE HOLDER	1		
3	09116-08122-000	BOLT (8X30)	2		
4	09202-06023-000	PIN, KNOCK (6X10)	2		
5	09282-12017-000	SEAL, DRIVE SHAFT UPPER OIL (11X24X4.5)	1		
6	16515-99J00-000	HOSE, OIL	1		
7	09401-15404-000	CLIP	1		
8	54112-99J00-000	BOLT, UPR MOUNT (L:123)	2		
9	54113-99J00-000	WASHER, UPR MOUNT BOLT	2		
10	54120-99J00-000	MOUNT, UPR THRUST	1		
11	54122-99J00-000	SPACER, UPR MOUNT (10.2X16X15)	2		
12	54125-99J00-000	STOPPER, UPR REVERSE THRUST	2		
13	54126-99J00-000	STOPPER, UPR THRUST	1		
13	54126-99JL0-000	STOPPER, UPR THRUST	1		DF8A:110001~, DF9.9A:110001~
14	54130-99J00-000	MOUNT, UPPER	2		
15	54148-99J00-000	COVER, UPR MOUNT	2		
16	09116-08137-000	BOLT, UPR MOUNT COVER (8X22)	4		
17	09140-10031-000	NUT, UPR MOUNT (M10)	2		

DP005687.TIF DF8ALK11(P1) K11 2011 / DRIVE SHAFT HOUSING

FIG.28


DF8A 9.9A P01_028
DRIVE SHAFT HOUSING

Part List

DP005687.TIF DF8ALK11(P1) K11 2011 / DRIVE SHAFT HOUSING

REF NO	PART NO	DESCRIPTION	QTY	KIT	NOTES
1	17565-99J00-000	GUIDE, WATER TUBE	1		
2	17913-93J00-000	PLUG, WATER	1		
3	17914-93J00-000	GASKET, WATER PLUG	1		
4	52110-99J00-0EP	HOUSING, DRIVE SHAFT (S)	1		
4	52110-99J10-0EP	HOUSING, DRIVE SHAFT (L)	1		
5	52113-99J00-000	GASKET, DRIVE SHAFT HSG	1		
6	57135-99J00-000	GUIDE, DRIVE SHAFT	1		
7	09100-08228-000	BOLT, DRIVE SHAFT HSG (8X105)	4		
8	09116-08122-000	BOLT, DRIVE SHAFT HSG (8X30)	4		
9	09160-08082-000	WASHER, DRIVE SHAFT HSG (8.5X16X1.2)	4		
10	09202-06023-000	PIN, KNOCK (6X10)	2		
11	09168-12017-000	GASKET, DRAIN PLUG (12X17X1)	1		
12	09248-12009-000	PLUG, DRAIN (12X18.65)	1		
13	17561-99J00-000	TUBE, WATER (S)	1		
13	17561-99J10-000	TUBE, WATER (L)	1		
14	17563-94J00-000	GROMMET, WATER TUBE	1		
15	54151-99J00-000	MOUNT, LWR THRUST	1		
16	54167-99J00-000	MOUNT, LWR SIDE	2		
17	54211-99J00-0EP	COVER, LWR MOUNT STBD	1		
18	54221-99J00-0EP	COVER, LWR MOUNT PORT	1		
19	54213-93901-000	PIN, KNOCK	2		
20	09116-08138-000	BOLT, LWR MOUNT COVER (8X40)	2		

DP005679.TIF DF8ALK11(P1) K11 2011 / GEAR CASE

FIG.29


DF8A 9.9A P01_029
GEAR CASE

Part List

DP005679.TIF DF8ALK11(P1) K11 2011 / GEAR CASE

REF NO	PART NO	DESCRIPTION	QTY	KIT	NOTES
1	55100-99J10-0EP	CASE, GEAR	1		
2	09263-15046-000	BEARING	1	*	
3	09262-25003-000	BEARING	1	*	
4	09202-06023-000	PIN, KNOCK (6X10)	2		
5	09116-08122-000	BOLT, GEAR CASE (8X30)	4		
6	55321-87J00-000	ANODE, PROTECTION	1		
7	09103-06281-000	BOLT (6X14)	1		
8	59178-97J00-000	GASKET, DRAIN PLUG	2		
9	09248-08001-000	PLUG, DRAIN (8X7.5)	2		
10	56120-99J10-0EP	HOUSING, PROPELLER SHAFT	1		
10	56120-99J20-0EP	HOUSING, PROPELLER SHAFT	1		DF8A:110001~, DF9.9A:110001~
11	08110-60050-000	BEARING	1	*	
12	09280-57002-000	O RING (D:3.5 ID:56.6)	1	*	
12	09280-57L01-000	O RING (D:3.5 ID:56.6)	1	*	DF8A:110001~, DF9.9A:110001~
13	09289-17006-000	OIL SEAL (16X30X6)	2	*	
14	29116-93J00-000	BOLT (6X20)	2		
15	58100-93703-019	PROPELLER, 3X9-1/4X7 (M701)	1		
15	58100-94J00-019	PROPELLER, 3X9-1/4X9 (M901)	1		
15	58100-93733-019	PROPELLER, 3X9-1/4X10 (M1001)	1		
15	58100-93743-019	PROPELLER, 3X9-1/4X11 (M1101)	1		
15	58100-91D00-019	PROPELLER, 3X9-1/4X8 (M811)	1		
15	58100-93763-019	PROPELLER, 3X9-1/4X9 (M911)	1		
15	58100-93773-019	PROPELLER, 3X9-1/4X10 (M1011)	1		
16	58120-93701-000	BUSH, PROPELLER	1	*	
17	57632-94J00-000	STOPPER, PROPELLER BUSH	1		
18	57630-99J00-000	NUT KIT, PROPELLER	1		OPT
19	57633-93901-000	SPACER, PROPELLER NUT	1	*	
20	09141-12005-000	NUT	1	*	
21	09160-12066-000	WASHER (12.5X22X2.5)	1	*	
22	09204-02004-000	PIN, COTTER	1	*	
23	55331-99J00-000	CORE, EXHAUST SEAL	1		
24	55332-99J00-000	RUBBER, EXHAUST SEAL	1		
25	55300-95500-000	ZINC ASSY, PROTECTION	1		OPT
26	09126-06006-000	SCREW (6X20)	2	*	OPT
27	29141-93J00-000	NUT	2	*	OPT
28	29162-93J00-000	WASHER	2	*	OPT
29	17917-87L00-000	CONNECTOR, FLUSH WATER	1		OPT,NOT SHOWN
30	55321-87J10-000	ANODE (MAGNESIUM)	1		OPT,NOT SHOWN

DP005696.TIF DF8ALK11(P1) K11 2011 / SIDE COVER


FIG.30DF8A 9.9A P01_030
SIDE COVER

Part List

DP005696.TIF DF8ALK11(P1) K11 2011 / SIDE COVER

REF NO	PART NO	DESCRIPTION	QTY	KIT	NOTES
1	61810-99J00-0EP	COVER, SIDE STBD	1	*	
2	61155-94500-000	TUBE, WATER INSP	1		
3	61821-99J00-0EP	COVER, SIDE PORT	1		
4	61815-99J00-000	SCREW, SIDE COVER (6X35)	8		
5	61112-99J00-000	RUBBER, SIDE COVER	1		
6	61134-99J00-000	SEAL, SIDE COVER	1		
6	61134-99JL0-000	SEAL, SIDE COVER	1		DF8A:110001~, DF9.9A:110001~
7	61157-99J00-000	HOSE, WATER INSPECTION	1		
8	09401-08413-000	CLIP, WATER INSPECTION HOSE	2		
9	09403-12316-000	CLAMP, WATER INSPECTION HOSE	1		
10	61851-93E10-000	PROTECTOR, SIDE COVER	2		
11	59139-94J00-000	SCREW, PROTECTOR	4		
12	61831-99J00-0EP	PANEL, INSTRUMENT	1		
13	09116-06133-000	BOLT, FRONT PANEL (6X25)	2		
14	09169-06075-000	WASHER, FRONT PANEL	2		
15	09320-09039-000	CUSHION, FRONT PANEL	2		
16	09148-06017-000	NUT, FRONT PANEL	2		
17	02142-06167-000	SCREW, FRONT PANEL	2		
18	61412-99J00-000	HOOK, FRONT PANEL	1		
19	61643-99J00-000	SCREW, HOOK	2		
20	09160-05029-000	WASHER, HOOK SCREW (5.5X12X0.8)	2		
21	61610-93901-000	FASTENER	1		
22	61616-93E00-000	PIN, LEVER	1		
23	61642-99J00-000	HOLDER, FASTENER LEVER	1		
24	09161-04012-000	WASHER, FASTENER LEVER PIN (4.2X11X1)	1		
25	09385-04003-000	PIN, SNAP	1		
26	29103-93J00-000	BOLT, HOLDER (6X12)	1		
27	08310-00067-000	NUT, FASTENER HOLDER	1		
28	09160-06082-000	WASHER, HOLDER NUT (6.5X13X1)	1		
29	61124-99J00-000	GROMMET, CABLE (STBD)	1		EXCEPT TYPE:R
29	61124-99J10-000	GROMMET, R/CON CABLE (STBD)	1		TYPE:R
30	61151-99J00-000	CUSHION, SIDE COVER HOLDER	1		
31	61827-99J00-000	HOLDER, SIDE COVER	1		MANUAL STARTER
32	02142-06167-000	SCREW, SIDE COVER HOLDER	1		MANUAL STARTER

DP005673.TIF DF8ALK11(P1) K11 2011 / ENGINE COVER


FIG.31DF8A 9.9A P01_031
ENGINE COVER

Part List

DP005673.TIF DF8ALK11(P1) K11 2011 / ENGINE COVER

REF NO	PART NO	DESCRIPTION	QTY	KIT	NOTES
1	61400-99J01-0EP	COVER ASSY, ENGINE	1		
2	61433-99J00-000	COVER, AIR INTAKE INNER	1	*	
3	03542-05169-000	SCREW	4	*	
4	61443-99J00-000	STRIPE, ENGINE COVER STBD	1		
5	61453-99J00-000	STRIPE, ENGINE COVER PORT	1		
6	68111-99J00-000	EMBLEM (S)	1		
7	61435-99J00-000	MARK, EMBLEM REAR (8)	1		DF8A
8	61435-99J10-000	MARK, EMBLEM REAR (9.9)	1		DF9.9A
9	61458-99E31-000	LABEL, ENGINE COVER	1		
9	61458-91J20-000	LABEL, ENGINE COVER	1		DF8A:010867~, DF9.9A:011403~
10	59800-99J01-000	TOOL ASSY	1		
11	68110-96110-000	COVER, WEATHER	1		OPT

DP005671.TIF DF8ALK11(P1) K11 2011 / FUEL TANK (RESIN)


FIG.32DF8A 9.9A P01_032
FUEL TANK (RESIN)

Part List

DP005671.TIF DF8ALK11(P1) K11 2011 / FUEL TANK (RESIN)

REF NO	PART NO	DESCRIPTION	QTY	KIT	NOTES
1	65000-99100-000	TANK ASSY, FUEL (12L)	1		
2	65520-99100-000	CAP ASSY, FUEL TANK	1	*	
3	65561-95D00-000	GASKET, TANK CAP	1	*	
4	65831-95D00-000	FILTER, OUTLET	1	*	
5	65890-99100-000	OUTLET	1	*	
6	65892-95D00-000	O RING	1	*	
7	65740-99100-000	PLUG, FUEL CONNECTOR	1	*	
8	65700-91113-000	HOSE, FUEL	1		
9	65750-87111-000	SOCKET, FUEL HOSE	1	*	
10	65750-98505-000	SOCKET, FUEL HOSE	1	*	
11	65770-93904-000	PUMP, SQUEEZE	1	*	
12	65781-98500-000	CLIP	4	*	
13	65720-986B0-000	PLUG, FUEL CONNECTOR	1		
14	09103-06237-000	BOLT	1		
15	09160-06085-000	WASHER (6.5X15X1)	1		

DP005982.TIF DF8ALK11(P1) K11 2011 / TILLER HANDLE (EXCEPT TYPE:R)

FIG.33

DF8A 9.9A P01_033

TILLER HANDLE (EXCEPT TYPE:R)


Part List

DP005982.TIF DF8ALK11(P1) K11 2011 / TILLER HANDLE (EXCEPT TYPE:R)

REF NO	PART NO	DESCRIPTION	QTY	KIT	NOTES
1	63111-99J10-0EP	HANDLE, TILLER	1		
2	63114-99J00-000	PLATE, WIRING INDICATOR	1		
3	63115-99J00-000	BUSH, TILLER HANDLE NO.2	1		
4	63115-99J10-000	BUSH, TILLER HANDLE NO.1	1		
5	63116-99J00-000	RUBBER, FRICTION	1		
6	63121-99J00-0EP	COVER, TILLER HANDLE	1		
7	63122-99J00-000	PROTECTOR, HANDLE COVER	1		
8	63131-99J00-0EP	BRACKET, TILLER HANDLE	1		
9	63133-99J00-000	GROMMET, TILLER HANDLE	1		
10	63210-99J00-000	GRIP, THROTTLE	1		
11	63221-99J00-000	ROD, THROTTLE	1		
12	63225-99J00-000	BUSH, SHIFT ROD	1		
13	63226-99J00-000	BUSH, THROTTLE / SHIFT ROD	1		
14	63228-99J00-000	HOLDER, HANDLE ROD	1		
15	63244-99J00-000	KNOB, ADJUSTER	1		
16	63245-99J00-000	BUSH, ADJUSTER	1		
17	63246-99J00-000	STOPPER, ADJUSTER	1		
18	63247-99J00-000	PLATE, ADJUSTER KNOB	1		
19	63248-99J00-000	PLATE, ADJUSTER NOTCH	1		
20	63340-99J00-000	GRIP, SHIFT	1		
21	63344-99J00-000	STOPPER, SHIFT ROD	1		
22	63345-99J00-000	SPRING, SHIFT GRIP	1		
23	63350-99J00-000	ROD, SHIFT	1		
24	63353-99J00-000	PLATE, SHIFT NOTCH	1		
24	63353-99JL0-000	PLATE, SHIFT NOTCH	1		DF8A:110001~, DF9.9A:110001~
25	63354-99J00-0EP	HOLDER, SHIFT NOTCH	1		
26	63355-99J00-000	BOLT, SHIFT NOTCH SPRING	1		
27	63610-99J00-000	CABLE ASSY, THROTTLE	2		
28	63640-99J00-000	CABLE ASSY, SHIFT	2		
29	09116-06094-000	BOLT, HDL SHIFT NOTCH HOLDER	2		
30	09116-06094-000	BOLT, THROTTLE ADJ STOPPER	1		
31	09116-06094-000	BOLT, THROTTLE ROD HOLDER	2		
32	09116-08122-000	BOLT, HANDLE COVER	2		
33	09116-08131-000	BOLT, HANDLE BRACKET	2		
34	09125-05042-000	SCREW, HANDLE COV PROTECTOR	1		
35	09126-06025-000	SCREW, THROTTLE GRIP	1		
36	09126-06025-000	SCREW, SHIFT GRIP	1		
37	09140-08023-XC0	NUT, SHIFT NOTCH PLATE	1		
38	09160-08082-000	WASHER, SHIFT NOTCH PLATE	1		
39	09160-10082-000	WASHER, SHIFT GRIP SPRING NO.1	1		
40	09160-10114-000	WASHER, SHIFT GRIP SPRING NO.2	1		
41	09163-06001-000	WASHER, HANDLE GRIP SCREW	1		
42	09163-06001-000	WASHER, SHIFT GRIP SCREW	1		
43	09202-04023-000	PIN, SHIFT GRIP	1		
44	09260-10006-000	BALL, SHIFT NOTCH	1		
45	09260-10006-000	BALL, THROTTLE ADJ NOTCH	1		
46	09403-13408-000	CLAMP, SW LEAD	1		
47	09440-06037-000	SPRING, THROTTLE ADJ NOTCH	1		
48	09440-07079-000	SPRING, SHIFT NOTCH	1		
49	03522-05169-000	SCREW, THROTTLE ADJ KNOB PLATE	3		
50	63215-93110-000	MARK, HANDLE GRIP	1		
50	63215-99JL0-000	MARK, HANDLE GRIP	1		DF8A:110001~, DF9.9A:110001~
51	37830-99J01-000	SWITCH ASSY, EMERGENCY	1		

52	09160-12067-000	WASHER, EMERGENCY SW	1	
53	37835-95D00-000	LABEL, STOP	1	
54	33833-91100-000	TUBE, SW LEAD	1	

DP005700.TIF DF8ALK11(P1) K11 2011 / REMOTE CONTROL (TYPE:R)

FIG.34

DF8A 9.9A P01_034
REMOTE CONTROL (TYPE:R)


Part List

DP005700.TIF DF8ALK11(P1) K11 2011 / REMOTE CONTROL (TYPE:R)

REF NO	PART NO	DESCRIPTION	QTY	KIT	NOTES
1	67200-94J12-000	REMOTE CONTROL ASSY	1		
2	09100-08232-000	BOLT	1	*	
3	36628-92E00-000	GROMMET, WIRE HARNESS	1	*	
4	37110-94J00-000	SWITCH ASSY, IGNITION	1	*	
5	37141-99E00-000	KEY (931)	1	**	
5	37141-99E10-000	KEY (932)	1	**	
5	37141-99E20-000	KEY (933)	1	**	
5	37141-99E30-000	KEY (934)	1	**	
5	37141-99E40-000	KEY (935)	1	**	
5	37141-99E50-000	KEY (936)	1	**	
5	37141-99E60-000	KEY (937)	1	**	
5	37141-99E70-000	KEY (938)	1	**	
5	37141-99E80-000	KEY (939)	1	**	
5	37141-99E90-000	KEY (940)	1	**	
5	37141-99EA0-000	KEY (941)	1	**	
5	37141-99EB0-000	KEY (942)	1	**	
6	37143-99E00-000	CAP, KEY	1	**	
7	37721-93J90-000	SWITCH, NEUTRAL	1	*	
8	37820-93J03-000	SWITCH ASSY, EMERGENCY	1	*	
9	37823-92E01-000	PLATE	1	**	
10	68165-16B00-13L	EMBLEM, SUZUKI	1	*	
11	38500-93J00-000	BUZZER	1	*	
12	67212-95600-000	WASHER	1	*	
13	67213-92E00-000	BRACKET, BUZZER	1	*	
14	09125-05042-000	SCREW, BUZZER BRKT	1	*	
15	67296-92E10-000	SCREW, NEUTRAL SW	2	*	
16	67220-95630-000	PLATE ASSY	1	*	
17	67223-99E10-000	KNOB, BRAKE ADJ	1	*	
18	67229-95600-000	ROLLER	1	*	
19	67232-95600-000	BUSH	1	*	
20	67238-87D00-000	GEAR, DRIVE	1	*	
21	67241-99E10-000	LEVER, FREE THROTTLE	1	*	
22	67243-95600-000	BUSH	1	*	
23	67244-95600-000	WASHER, WAVE	1	*	
24	67245-95600-000	DRUM, FREE THROTTLE	1	*	
25	67251-99E10-000	LEVER, HANDLE	1	*	
26	67252-95600-000	BUSH	2	*	
27	67253-95600-000	WASHER	1	*	
28	67255-99E00-000	ARM, LOCK	1	*	
29	67256-95600-000	HOLDER, NEUT LOCK	1	*	
30	67257-99E00-000	CAP, LEVER	1	*	
31	67258-99E00-000	BRACKET, LOCK ARM	1	*	
32	67259-87D00-000	SPRING, NEUTRAL ARM	1	*	
33	67261-99E00-000	GRIP	1	*	
34	67296-94310-000	SCREW	1	*	
35	67264-95600-000	WASHER	1	*	
36	67267-95610-000	COVER, WIRE	1	*	
37	67273-95600-000	SPACER	1	*	
38	67275-95600-000	END, CABLE	2	*	
39	67288-92E00-000	WASHER, BRAKE ADJ KNOB	1	*	
40	67292-94300-000	E RING	3	*	
41	67294-95600-000	SPACER	3	*	
42	67296-90J00-000	SCREW	5	*	
43	67296-94300-000	SCREW	2	*	
44	67296-95600-000	SCREW	3	*	
45	67296-95610-000	SCREW	2	*	
46	67297-95600-000	WASHER	2	*	
47	09126-05003-000	SCREW	2	*	
48	09140-06020-000	NUT	3	*	
49	09160-06104-000	WASHER	3	*	
49A	37859-90J00-000	SPACER	1	*	

50	36620-94J01-000	WIRE ASSY, REMOTE CONTROL	1		
51	09481-10501-000	FUSE (10A)	1	*	
52	67320-93J00-000	CABLE, REMOCON 8F (2.4M)	2		OPT
52	67320-93J10-000	CABLE, REMOCON 10F (3.1M)	2		OPT
52	67320-93J20-000	CABLE, REMOCON 12F (3.7M)	2		OPT
52	67320-93J30-000	CABLE, REMOCON 14F (4.2M)	2		OPT
52	67320-93J40-000	CABLE, REMOCON 16F (4.8M)	2		OPT
52	67320-93J50-000	CABLE, REMOCON 18F (5.4M)	2		OPT
52	67320-93J60-000	CABLE, REMOCON 20F (6.0M)	2		OPT
52	67320-93J70-000	CABLE, REMOCON 22F (6.7M)	2		OPT
52	67320-93J80-000	CABLE, REMOCON 24F (7.3M)	2		OPT

DP005655.TIF DF8ALK11(P1) K11 2011 / REMOCON CABLE HOLDER (TYPE:R)

FIG.35


DF8A 9.9A P01_035
REMOCON CABLE HOLDER (TYPE:R)

Part List

DP005655.TIF DF8ALK11(P1) K11 2011 / REMOCON CABLE HOLDER (TYPE:R)

REF NO	PART NO	DESCRIPTION	QTY	KIT	NOTES
1	67467-89J01-000	CONNECTOR, R/CON CABLE	2		
2	09160-06055-000	WASHER, R/CON CABLE CONNECTOR (7X12X1)	2		
3	09385-06012-000	CLIP, R/CON CABLE CONNECTOR	2		
4	67340-99J00-000	HOLDER, REMOCON CABLE	1		
5	01550-06167-000	BOLT, REMOCON CABLE HOLDER	2		

DP005653.TIF DF8ALK11(P1) K11 2011 / DRAG LINK (TYPE:R)

FIG.36


DF8A 9.9A P01_036
DRAG LINK (TYPE:R)

Part List

DP005653.TIF DF8ALK11(P1) K11 2011 / DRAG LINK (TYPE:R)

REF NO	PART NO	DESCRIPTION	QTY	KIT	NOTES
1	41161-94400-000	SEAL, STEERING CABLE	1		
2	67701-99J00-000	LINK ASSY, DRAG	1		
3	67721-89J00-000	SPACER	1	*	
4	67725-99J00-000	BOLT	1	*	
5	67726-99E00-000	NUT	2	*	
6	67728-99E00-000	WASHER	3	*	
7	99011-99J02-055	MANUAL, OWNER'S	1		NOT SHOWN
7	99011-99J01-055	MANUAL, OWNER'S	1		DF8A:110001~, DF9.9A:110001~

DP005680.TIF DF8ALK11(P1) K11 2011 / OPT:ELECTRICAL (MANUAL STARTER)

FIG.37

DF8A 9.9A P01_037
OPT:ELECTRICAL (MANUAL STARTER)


Part List

DP005680.TIF DF8ALK11(P1) K11 2011 / OPT:ELECTRICAL (MANUAL STARTER)

REF NO	PART NO	DESCRIPTION	QTY	KIT	NOTES
1	32000-99J00-000	KIT, BATTERY CHARGING	1		
2	32801-95J01-000	RECTIFIER/REGULATOR SET	1	*	
3	32800-95J01-000	RECTIFIER/REGULATOR ASSY	1	**	
4	36615-96300-000	TERMINAL, RESIN	2	**	
5	29404-93J10-000	CLAMP, RECT/RGLTR LEAD	1	**	
6	09407-14407-000	CLAMP, HARNESS	1	**	
7	09408-00024-000	CLAMP, HARNESS	1	**	
8	01550-06257-000	BOLT	2	**	
9	39600-94J01-000	RECEPTACLE SET	1	*	
10	33816-94J01-000	CLAMP, CABLE	1	**	
11	36740-94J00-000	CASE ASSY, FUSE	1	**	
12	37801-98300-000	LEAD RECEPTACLE GROUND	1	**	
13	39601-95D00-000	RECEPTACLE ASSY, LIGHTING	1	**	
14	36634-93910-000	CAP	1	***	
15	39602-93900-000	PLUG, RECEPTACLE	1	**	
16	39603-94400-000	GROMMET.RECEPTACLE	1	**	
17	09407-14407-000	CLAMP, RECEPTACLE LEAD	1	**	
17	09407-25402-000	CLAMP, RECEPTACLE GROMMET	1	**	
18	09407-14403-000	CLAMP, HARNESS	2	**	
19	03241-0625A-000	SCREW, CABLE CLAMP	1	**	
20	36990-87D00-000	TERMINAL & SLEEVE SET	1		
21	34200-93J20-000	TACHOMETER ASSY	1		BLACK
21	34200-93J31-000	TACHOMETER ASSY	1		WHITE
22	36615-96300-000	TERMINAL, RESIN	4	*	
23	09471-12028-000	BULB	1	*	

DP005651.TIF DF8ALK11(P1) K11 2011 / OPT:STARTING MOTOR (MANUAL STARTER)

FIG.38



DF8A 9.9A P01_038
OPT:STARTING MOTOR (MANUAL STARTER)


Part List

DP005651.TIF DF8ALK11(P1) K11 2011 / OPT:STARTING MOTOR (MANUAL STARTER)

REF NO	PART NO	DESCRIPTION	QTY	KIT	NOTES
1	31000-99J00-000	STARTER SET, ELECTRIC	1		
2	12625-99J00-000	BASE, STATOR	1	*	NOT SHOWN,REFER TO FIG.4
3	31101-99J00-000	MOTOR SET, STARTING	1	*	NOT SHOWN
4	31100-94J21-000	MOTOR ASSY, STARTING	1	**	NOT SHOWN
5	31912-99J00-000	BAND	1	**	NOT SHOWN,REFER TO FIG.19
6	31918-94J00-000	DAMPER	1	**	NOT SHOWN,REFER TO FIG.19
7	38860-76F01-000	RELAY ASSY	1	**	NOT SHOWN,REFER TO FIG.19
8	38915-90J00-000	HOLDER	1	**	NOT SHOWN,REFER TO FIG.19
9	01550-06167-000	BOLT, LOWER	2	**	NOT SHOWN,REFER TO FIG.19
10	01550-08257-000	BOLT, UPPER	2	**	NOT SHOWN,REFER TO FIG.19
11	08316-10087-000	NUT	1	**	NOT SHOWN,REFER TO FIG.19
12	32104-99J00-000	MAGNETO SET	1	*	NOT SHOWN
13	32102-99J00-000	FLYWHEEL, MAGNETO	1	**	NOT SHOWN,REFER TO FIG.20
14	32120-99J00-000	COIL, STATOR & PULSER	1	**	NOT SHOWN,REFER TO FIG.20
15	09125-06035-000	SCREW, STATOR COIL	3	*	NOT SHOWN,REFER TO FIG.20
16	32801-99J00-000	RECTIFIER/REGULATOR SET	1	*	NOT SHOWN
17	32800-99J00-000	RECTIFIER/REGULATOR ASSY	1	**	NOT SHOWN,REFER TO FIG.21
18	01550-06257-000	BOLT, RECTIFIER	2	**	NOT SHOWN,REFER TO FIG.21
19	32900-99J00-000	UNIT, CDI	1	*	NOT SHOWN,REFER TO FIG.21
20	33800-99J00-000	CABLE SET, STARTING	1	*	NOT SHOWN
21	33810-99J00-000	CABLE, STARTER	1	**	NOT SHOWN,REFER TO FIG.23
22	36655-99J00-000	PLATE, CABLE GROMMET	1	**	NOT SHOWN
23	36656-99J20-000	GROMMET, CABLE (PORT)	1	**	NOT SHOWN
24	37161-89E13-000	SWITCH ASSY, STARTER	1	**	NOT SHOWN,REFER TO FIG.22
25	37721-99J10-000	SWITCH ASSY, NEUTRAL	1	**	NOT SHOWN,REFER TO FIG.22
26	37724-99J00-000	ROD, SWITCH PUSH	1	**	NOT SHOWN,REFER TO FIG.22
27	37726-99J10-000	BRACKET, NEUTRAL SW	1	**	NOT SHOWN,REFER TO FIG.22
28	09137-04004-000	BOLT, NEUTRAL SW BRACKET	2	**	NOT SHOWN,REFER TO FIG.22
29	09159-14014-000	NUT, STARTER SW	1	**	NOT SHOWN,REFER TO FIG.22
30	36610-99J00-000	HARNESS ASSY, WIRING	1	*	NOT SHOWN,REFER TO FIG.23
31	09407-14403-000	CLAMP	2	*	NOT SHOWN,REFER TO FIG.23
32	09407-14407-000	CLAMP	4	*	NOT SHOWN,REFER TO FIG.23

DP005675.TIF DF8ALK11(P1) K11 2011 / OPT:FUEL TANK (RESIN 25L)

FIG.39




DF8A 9.9A P01_039
OPT:FUEL TANK (RESIN 25L)

Part List

DP005675.TIF DF8ALK11(P1) K11 2011 / OPT:FUEL TANK (RESIN 25L)

REF NO	PART NO	DESCRIPTION	QTY	KIT	NOTES
1	65000-95D01-000	TANK ASSY, FUEL (25L)	1		
2	65520-95D00-000	CAP, FUEL TANK	1	*	
3	65561-95D00-000	GASKET, TANK CAP	1	*	
4	65740-95D01-000	PLUG, FUEL CONNECTOR	1	*	
5	65831-95D00-000	FILTER, OUTLET	1	*	
6	65890-95D00-000	OUTLET ASSY	1	*	
7	65892-95D00-000	O RING	1	*	
8	65700-87J13-000	HOSE, FUEL	1		
9	65750-87J11-000	SOCKET, FUEL HOSE	1	*	
10	65750-95500-000	SOCKET, FUEL HOSE	1	*	
11	65770-95505-000	PUMP, SQUEEZE	1	*	
12	65781-98500-000	CLIP	4	*	

DP005650.TIF DF8ALK11(P1) K11 2011 / OPT:REMOTE CONTROL PARTS


FIG.40DF8A 9.9A P01_040
OPT:REMOTE CONTROL PARTS

Part List

DP005650.TIF DF8ALK11(P1) K11 2011 / OPT:REMOTE CONTROL PARTS

REF NO	PART NO	DESCRIPTION	QTY	KIT	NOTES
1	67130-99J00-000	PARTS SET, REMOTE CONTROL	1		
2	19120-99J10-000	DRUM, THROTTLE CONTROL	1		NOT SHOWN,REFER TO FIG.13
3	19122-99J00-000	LEVER, INTERLINK THROTTLE NO.2	1		NOT SHOWN,REFER TO FIG.13
4	19184-99J10-000	PLATE, THROTTLE LINK	1		NOT SHOWN,REFER TO FIG.13
5	19185-99J00-000	SPRING, THROTTLE LEVER	1		NOT SHOWN,REFER TO FIG.13
6	21241-99J00-000	LINK, CLUTCH LEVER	1		NOT SHOWN,REFER TO FIG.16
7	23210-99J00-000	LEVER, CLUTCH CONTROL	1		NOT SHOWN,REFER TO FIG.16
8	09204-01002-000	PIN, CLUTCH LEVER LINK	1		NOT SHOWN,REFER TO FIG.16
9	09160-05029-000	WASHER, CL LINK LEVER (5.5X12X0.8)	2		NOT SHOWN,REFER TO FIG.16
10	09385-04003-000	CLIP, CL LEVER LINK	1		NOT SHOWN,REFER TO FIG.16
11	43755-99J00-000	ATTACHMENT, STRG BRKT	1		NOT SHOWN,REFER TO FIG.26
12	09108-08286-000	BOLT, ATTACHMENT STUD	2		NOT SHOWN,REFER TO FIG.26
13	09159-08059-000	NUT, ATTACHMENT (M8)	2		NOT SHOWN,REFER TO FIG.26
14	09160-08082-000	WASHER, ATTACHMENT (8.5X16X1.2)	2		NOT SHOWN,REFER TO FIG.26
15	36360-99J10-000	INDICATOR, OIL PRESSURE	1		NOT SHOWN,REFER TO FIG.22
16	36610-99J20-000	HARNESS ASSY, WIRING	1		NOT SHOWN,REFER TO FIG.23
17	09481-20501-000	FUSE (20A)	1	*	NOT SHOWN,REFER TO FIG.23
18	36656-99J10-000	GROMMET, CABLE (PORT)	1		NOT SHOWN,REFER TO FIG.23
19	09407-14403-000	CLAMP, HARNESS	1		NOT SHOWN,REFER TO FIG.23
20	09407-14407-000	CLAMP, HARNESS	1		NOT SHOWN,REFER TO FIG.23
21	61124-99J10-000	GROMMET, R/CON CABLE (STBD)	1		NOT SHOWN,REFER TO FIG.30
22	67467-89J01-000	CONNECTOR, R/CON CABLE	2		NOT SHOWN,REFER TO FIG.35
23	09160-06055-000	WASHER, R/CON CABLE CONNECTOR (7X12X1)	2		NOT SHOWN,REFER TO FIG.35
24	09385-06012-000	CLIP, R/CON CABLE CONNECTOR	2		NOT SHOWN,REFER TO FIG.35
25	67340-99J00-000	HOLDER, REMOCON CABLE	1		NOT SHOWN,REFER TO FIG.35
26	01550-06167-000	BOLT, REMOCON CABLE HOLDER	2		NOT SHOWN,REFER TO FIG.35

DP005694.TIF DF8ALK11(P1) K11 2011 / OPT:TOP MOUNT SINGLE (1)

FIG.41


DF8A 9.9A P01_041
OPT:TOP MOUNT SINGLE (1)

Part List

DP005694.TIF DF8ALK11(P1) K11 2011 / OPT:TOP MOUNT SINGLE (1)

REF NO	PART NO	DESCRIPTION	QTY	KIT	NOTES
1	67200-93J12-000	REMOTE CONTROL ASSY	1		PUSH
2	67261-93J00-000	GRIP, NO.1	1	*	
3	67263-93J00-000	GRIP, NO.2	1	*	
4	37850-93J10-000	SWITCH ASSY, PTT	1	*	
5	67295-92E10-000	SCREW	2	*	
6	67296-88D10-000	SCREW	1	*	
7	67288-92E20-000	WASHER	3	*	
8	67295-92E00-000	SCREW	2	*	
9	67296-92E70-000	SCREW	1	*	
10	67288-92E40-000	WASHER	1	*	
11	67257-92E00-000	CAP, LEVER	1	*	
12	67251-93J00-000	LEVER, HANDLE	1	*	
13	67296-92E60-000	SCREW	2	*	
14	67288-92E30-000	WASHER	2	*	
15	67253-92E00-000	WASHER	1	*	
16	36890-93J00-000	WIRE HARNESS	1	*	
17	67281-93J00-000	DECAL	1	*	
18	67296-92E30-000	SCREW	4	*	
19	09160-05024-000	WASHER	4	*	
20	67287-92E00-000	NUT	4	*	
21	67275-95600-000	END, CABLE	2	*	
22	67273-95600-000	SPACER	1	*	
23	67273-92E00-000	GROMMET	1	*	
24	67274-92E00-000	FLANGE	2	*	
25	67296-95610-000	SCREW	4	*	
26	67271-92E00-000	COVER	1	*	
27	67211-93J00-000	COVER	1	*	
28	67296-92E70-000	SCREW	2	*	
29	67500-93J00-000	KIT, REMOCON SPACER SINGLE	1		
30	09125-05135-000	SCREW	4	*	
31	09160-05029-000	WASHER	4	*	
32	09140-05005-000	NUT	4	*	

DP005690.TIF DF8ALK11(P1) K11 2011 / OPT:TOP MOUNT SINGLE (2)

FIG.42

DF8A 9.9A P01_042
OPT:TOP MOUNT SINGLE (2)

Part List

DP005690.TIF DF8ALK11(P1) K11 2011 / OPT:TOP MOUNT SINGLE (2)

REF NO	PART NO	DESCRIPTION	QTY	KIT	NOTES
1	67200-93J12-000	REMOTE CONTROL ASSY	1		PUSH
2	67222-92E00-000	DUAL PLATE	1	*	
3	67223-92E00-000	BRAKE ADJUST	1	*	
4	67288-92E00-000	WASHER	1	*	
5	67292-94300-000	E RING	4	*	
6	67288-92E10-000	WASHER	1	*	
7	67291-92E00-000	SNAP RING	2	*	
8	67221-92E00-000	SHIFT ASSY	1	*	
9	67224-92E00-000	BRAKE ARM ASSY	1	*	
10	67294-92E00-000	SPACER	1	*	
11	37721-95500-000	SWITCH ASSY, N/R	1	*	
12	67296-92E10-000	SCREW (3X15)	2	*	
13	67296-88D10-000	SCREW (5X16)	2	*	
14	67296-92E20-000	SCREW (5X25)	2	*	
15	67226-92E00-000	BOLT, STOPPER FRONT	1	*	
16	67226-92E10-000	BOLT, STOPPER REAR	1	*	
17	67240-92E00-000	ARM ASSY, THROTTLE	1	*	
18	67228-92E00-000	WASHER	1	*	
19	67286-92E00-000	BOLT (6X18)	3	*	
20	67230-92E00-000	ARM ASSY, SHIFT	1	*	
21	09125-05042-000	SCREW (5X10)	9	*	
22	67234-92E00-000	CASE, GEAR	1	*	
23	67245-92E00-000	LEVER ASSY, THROTTLE	1	*	
24	67227-92E00-000	STOPPER	1	*	
25	09126-06006-000	SCREW (6X20)	2	*	
26	67225-92E00-000	SPRING	1	*	
27	09125-04004-000	SCREW (4X6)	1	*	
28	67233-92E00-000	SPRING	1	*	
29	67235-92E00-000	PLATE, SHIFT LOCK	1	*	
30	67232-95620-000	BUSH	1	*	
31	67269-92E00-000	BRACKET	1	*	
32	67296-88D10-000	SCREW	1	*	
33	09140-06020-000	NUT	2	*	
34	67236-92E00-000	ROLLER	1	*	
35	67237-92E01-000	SPRING	6	*	
36	67238-92E00-000	GEAR, DRIVE	1	*	
37	67239-92E00-000	PIN	1	*	
38	67246-92E00-000	SHIFT, DRIVE	1	*	
39	67252-92E00-000	BUSH	1	*	
40	67291-92E10-000	SNAP RING	1	*	
41	67253-92E10-000	WASHER	1	*	
42	67252-92E10-000	BUSH	1	*	
43	67253-95600-000	WASHER	1	*	
44	67231-92E00-000	GEAR, SHIFT	1	*	
45	67232-95600-000	BUSH	1	*	
46	67241-92E00-000	ROD, FREE ACC	1	*	
47	67243-92E00-000	GROMMET	1	*	
48	67239-92E10-000	PLATE, SHIFT PIN	1	*	